

Instructions for Display Setting

The display settings for bright stars and Messier objects can be changed. You can select from “Display”, “Hide” and “Zoomed Display”.

Procedures

- ① Press **Menu** to display the System Menu. Choose **Chart Setting** with the **↑**·**↓** keys and press **Select** to enter.



- ② The Chart Setting screen is displayed. Move the cursor with the **←**·**→** keys and select your setting preference with the **Value+**, **Value-** keys. Choose **OK** and press **Select** to enter.



- ③ If you choose **Always ON**, the names of the bright stars and Messier objects will be always displayed.



- ④ If you choose **Always OFF**, the names of the bright stars and Messier objects will be hid except for the name of the selected target.



- ⑤ If you press the **Zoom+** key, the star chart will be zoomed. If you press the **Zoom+** key once again, the star chart will be zoomed furthermore.

Zoom 1: Display of the first level zoom
 Zoom 2: Display of the second level zoom
 Zoom 3: Display of the third level zoom

